



# DR 609 BUILD MANUAL



# DR 609 INPUT TRANSFORMER WIRING


## CARNHILL VTB9046 WIRED OR MARINAIR 31267

PIN 6 CONNECTED TO CASE(GND)  
PIN 11 NOT CONNECTED




DR 609 FRONT PANEL BOARD V.1 WIRING

MAIN BOARD




FRONT PANEL BOARD

# DR 609 LINK, POWER TOGGLES AND LEDS WIRING




# DR 609 METER WIRING

MAIN BOARD PCB




DR 609 XLR CONNECTORS WIRING


OUTPUT XLR




INPUT XLR



EXT SC XLR




# DR 609 POWER SUPPLY SETUP



CONNECT PSU TO MAIN BOARDS AFTER ADJUSTMENTS


## TOROID WIRING FOR 115V



**FOLLOW THE EXTRA SHIELDING FOR AC WIRES AND A B C D AND X1 X2 X3 X4 PATTERNS!**




## TOROID WIRING FOR 230V



**FOLLOW THE EXTRA SHIELDING FOR AC WIRES AND A B C D AND X1 X2 X3 X4 PATTERNS!**

# DR 609 FRONT PANEL CONNECTORS




FRONT PANEL PCB REAR VIEW


# DR 609 INTERSTAGE TRANSFORMER WIRING

## CARNHILL VTB9045 WIRED OR MARINAIR 10468



PIN 6 CONNECTED TO CASE(GND)  
PIN 11 NOT CONNECTED




DR 609 OUTPUT TRANSFORMER WIRING  
CARNHILL VTB9056 OR MARINAIR LO1173



# DR 609 THRESHOLD ROTARY SWITCH




# DR 609 TRANSFORMERS PINOUT




INPUT\_XFRM

PIN 1 - PRIMARY +  
PIN 2 - PRIMARY -  
PIN 3 - SECONDARY +  
PIN 5 - SECONDARY -



INTERSTAGE\_XFRM

PIN 1 - PRIMARY +  
PIN 2 - PRIMARY -  
PIN 3 - SECONDARY +  
PIN 5 - SECONDARY -



OUT\_XFRM

PIN 1 - PRIMARY +  
PIN 2 - PRIMARY -  
PIN 3 - GND  
PIN 4 - SECONDARY +  
PIN 5 - SECONDARY -